


EC 26 WIRING DIAGRAM



POSITION

- (FORWARD) 1 BPN single-coil
 2 FPN + BPN single coils
 3 FPN HUMBUCKER
 4 FPN + BPN HUMBUCKERS
 (BACK) 5 BPN HUMBUCKER

TO: GUY MAY
 FROM: STEVE
 DAVES

The 100K RESISTORS ARE TO ATTENUATE THE HUMBUCKING MODES TO MATCH THE OUTPUT OF THE SINGLE COIL MODES.