

Washburn USA uses the Korg MT-1200 Tuner though any other programmable tuner will work.

# Instructions for Programming the MT-1200 Tuner for the Buzz Feiten Tuning System™

Turn on tuner.

Push MODE button twice until TEMP light illuminates.

Push < > cursor right until the display reads 0.

- Push **E**; display will flash
- Push **< ● >** OCTAVE buttons on the top right of the tuner to -2
- Push **< >** cursor on left down to -02; light will flash.
- Push **SET**; light will stop flashing.

To continue programming the tuner, repeat the bulleted instructions for each of the following offsets. Remember to press SET after each entry.

		Push <b>E</b>	OCTAVE -1 Cursor 00
Push <b>A</b>	OCTAVE -2 Cursor -02	Push <b>A</b>	OCTAVE -1 Cursor 00
Push <b>D</b>	OCTAVE -1 Cursor -02	Push <b>D</b>	OCTAVE 0 Cursor +01
Push <b>G</b>	OCTAVE -1 Cursor -02	Push <b>G</b>	OCTAVE 0 Cursor +01
Push <b>B</b>	OCTAVE -1 Cursor +01	Push <b>B</b>	OCTAVE 0 Cursor 00
Push <b>E</b>	OCTAVE 0 Cursor 00	Push <b>E</b>	OCTAVE +01 Cursor 00

**NEVER UNPLUG TUNER WHILE ON.  
PROGRAMMING YOU'VE JUST DONE WILL BE LOST!!  
CHANGE BATTERIES WITH AC PLUGGED IN.**



Washburn International  
255 Corporate Woods Parkway  
Vernon Hills, IL. 60061  
Phone (847)913-5511 • Fax: (847) 913-7772  
Email: washburn@washburn.com  
World Wide Web: <http://www.washburn.com>

