


# AUTOMATIC TUNER LT10 INSTRUCTION MANUAL

## Features & Functions



### 1. Power / Mode Switch

Select the type of instrument (GUITAR or BASS) you wish to tune by sliding this switch to the desired position. The selection of either mode will turn the tuner on. Slide the switch to OFF to turn the tuner off.

### 2. Tuning Guide LEDs

When the instrument is in tune, the Green LED in the middle will light up. If the pitch of the string is flat, the Red LED on the left will light up. If the pitch of the string is sharp, the Red LED on the right will light up.

### 3. Note Indicator LEDs

These LEDs indicate the note of the string you are tuning.

### 4. Microphone for Acoustic Guitar

To tune acoustic guitars or basses, place the tuner near the instrument for more accurate tuning. The microphone does not operate when the input jack is connected.

### 5. Input Jack for Instruments with Pickup

When you wish to tune instruments with pickup, connect the output cord or pickup of the instrument to the input jack. The Microphone does not operate when input jack is connected with instrument.

## Tuning Procedure

- 1. Input Jack for Instruments with Pickups:** Connect the output cord of the instrument to the input jack of the tuner. If possible, set the volume level of the instrument to the center position. Acoustic guitar: Place the instrument near the tuner microphone.
- 2. Select the type of instrument you are tuning by sliding the Power / Mode switch**
- 3. Start with a lower pitch (looser string) and then tune up to the correct pitch**
- 4. If the note shown on the Note Indicator LEDs is different from the one you wish, try tuning the string until the correct LED lights up. Be careful not to over-tune (over-tighten) with this method in order to avoid string breakage.**
- 5. The further away from the desired tuning note the guitar string is, the faster one of the Red LEDs will blink. The closer to the desired tuning note the string is, the slower the light will blink.**
- 6. When the Green LED in the middle of the Tuning Guide LEDs lights up, the correct tuning has been achieved.**

## Installation & Replacement of Battery

1. Press down on the battery cover (located on the back of the tuner) and slide it in the direction of the arrow.
2. Install two AAA (R03, LR03, L30) 1.5 volt batteries in the battery spaces, making sure that the batteries are facing the proper polarity direction.
3. Slide the battery cover back in the opposite direction.

## Caution

### To avoid short circuit, electric shock or malfunction

Do not disassemble. Repairs should be attempted only by qualified personnel.

Avoid placing the tuner in areas of high heat (heaters, direct sunlight, etc.) or humidity (bathrooms, wet floors, etc.).

Do not place on areas of excessive vibration such as PA speakers.

Do not place in dusty or dirty areas

Do not operate the tuner with wet hands

### To avoid breakdown

Handle controls without excessive force.

Do not allow the tuner to be dropped. Always transport the tuner in a protective case or bag.

### Cleaning

Use only a clean and dry cloth

Do not use thinner or alcohol for cleaning.

### To prevent battery loss

Remove the battery when the tuner will not be used for a long period of time.

Slide the power button off when the tuner is not in use.

### Battery

Use only 1.5V AAA-size (R03, LR03, L30)

LD10 Tuner  
Manual